



Setting Up HyperFIDO™ with Linux

03/02/2023

HSTE-NB0033.7-RV. 1.1

HYPERSECU INFORMATION SYSTEMS INC

200-6191 Westminster Hwy, Richmond BC, V7C 4V4 Canada
1-604-279-2000 | hypersecu.com

Table of Contents

HyperFIDO for Linux Operating Systems	1
Setting Up FIDO U2F with Linux	1
Download and Install the Rules File.....	1

HyperFIDO for Linux Operating Systems

This document will demonstrate how to set up a HyperFIDO U2F security key to use with a Linux operating system. For instructions on how to register and sign in to different services using HyperFIDO, see our other HyperFIDO user guides in the Support section of our website.

Setting Up FIDO U2F with Linux

Depending on your Linux operating system, you may be required to add a rules file to use your HyperFIDO security key. You can download and install the rules file through our website.

NOTE: You must have the root user privilege to perform this operation.

Download and Install the Rules File

To download and install the rules file:

1. Download the HYPERSECU® HyperFIDO Linux Rules file `70-u2f.zip` from hypersecu.com/downloads/
2. Unzip the file.
3. Copy the `70-u2f.rules` file to `/etc/udev/rules.d/`
4. Restart your computer.

If you already have the rules file from another U2F vendor, add the following into the current rules file and restart your computer:

```
# Hypersecu HyperFIDO
KERNEL=="hidraw*", SUBSYSTEM=="hidraw", ATTRS{idVendor}=="2ccf",
ATTRS{idProduct}=="0880|0850|0852|0853|0854|0856|0858|085a|085b",
TAG+="uaccess"
```